

List of Keyins

Keyin	Definition
Ax	Print last x power fails, default =1
AD_EPx	Print contents or A/D EEPROM x -non iso
AD_Ew	Write defaults to A/D EEPROM x - non iso
AD_CALx	Calibrate A/D board x - non iso
ALM	Print channels currently in alarm
BR(X)xx	Reset bit # xx (X) = O = Output, = I = Input, (X) not sent = Output
BS(X)xx	Set bit # xx (X) = 0 = Output, = I = Input, (X) not sent = Output
CFGUL	Upload configuration to RamPack
CFGDL	Download configuration from RamPack
CFGLOG	Print a log of configurations in RamPack
CP	CP aaaaaaa cc Print in hex the contents of the RamPack aaaaaaaa = starting address, cc = number of 64 byte blocks. CP<cr> uses defaults of 00010000(aaaaaaa) 04(cc). Add left @ aaaaaaa
CPHx	Prt Headers, x=0=00010000 x=1=0001140
CPW dd	Write data to memory location, read back, ADD = ADD+1
CsU	Allows clearing of setup parameters
D43	Lets comm port #4 communicate with instruments
E	Print error log
EC	Clear error log
ERASEp	Erase preliminary arrays
ERASEi	Erase interim arrays
ERASEcx	Erase stored calibrations day x (x=1, 2=yesterday ●●●)
ERASEf	Erase final arrays
ERASER	Erase RamPack
ERASERZ	Format RamPack
ERASERC	Format Configuration RamPack
Help	Print list of keyins
Helpme	Print expanded list of keyins
I	Brings up Main Menu
JC	Comm Port Test
JCGx	Sets All A/D Gains to x
L	Prints configuration set up
LC	Prints calibrator set up parameters
LCD	Toggles demo data for the bar & trend displays
MM	Brings up Main Menu on LCD
Mb aaaa cc	Prints RAM contents, b=bank, aaaa= address, cc=# 16 byte lines
OPRx	Print stored operator messages, x = 1-8 or A for all
OPWx	Allows writing message #x, or clearing with CLR,<cr>
PAC	Automatically print cal results
PAD	Print I/O settings on change
PARxx	Print response from instrument on channel #xx
PCx	Print cal results from day x (1=today, 2=yesterday ●●●)
PD	Print instantaneous I/O settings
PFx	Print final averages for x periods
Plx	Print interim averages for x periods
PMxxx	Print preliminary averages for x periods
PV	Print instantaneous data values
PVA	Print instantaneous A/D Values
PVS	Select scientific or engineering print formats
RESQ	Disconnects comm #1 signal lines to comm #4
SAOP	Send analog output strings to comm #4
SAO dd vvv	Set analog output number dd to value vvv% (>100% resets)
SETx	Switches comm #1 to Pass with comm port x (x=0-6)
SETQ	Switches comm #1 signal lines to Comm #4
SEQxx	Start/stop sequence xx
SEQ?	Print names, state of all sequences
T	Print present time & date
TC	Print RTC time/date
Tlxx	Send time & date to instrument on channel #xx

TF	Set mm/dd/yy or dd/mm/yy date format
TS	Set CPP time & date
U	Allows up/down channels
ZS	Enter zero & span values

>,010,CFF,000,<cr> Upload configuration over comm port